

MANUFACTURER:

SaverSystems
800 S 7th St.
Richmond, IN 47374
800-860-6327
www.1deck.com



DESCRIPTION

#1 Deck Wood Brightener is a liquid concentrate that is mixed with water to brighten and restore the natural beauty of all species of exterior wood. This product excels at removing dirt, grime, rust stains, and tannin stains caused by fallen leaves. #1 Deck Wood Brightener is a safe, oxalic acid product that will not only clean and brighten, but will neutralize the surface of the wood, creating an ideal surface that is ready to be stained. This product is step 2 of a 3 step system.

WHERE TO USE

#1 Deck Wood Brightener is intended for use on all types of weathered, exterior wood surfaces including decks, fences, siding, outdoor furniture, gazebos and playsets.

Recommended for surface preparation prior to initial application of semi-transparent finishes and stains. Product can be used as a cleaner and brightener for redwood, or as a neutralizer to further brighten wood species, like pine, that have been cleaned with #1 Deck Wood Cleaner or stripped with #1 Deck Stain Stripper. For lasting protection of your exterior wood, after using

#1 Deck Wood Brightener, treat the surface with #1 Deck Premium Wood Stain.

Note: #1 Deck Wood Brightener is not formulated to remove intact paint, stain, or clear finishes and may dull painted and metal surfaces if not quickly rinsed.

ADVANTAGES

- Neutralizes stain strippers
- Brightens and restores wood surfaces
- Improves absorption of wood stains

APPLICATION

Mix Well: Shake #1 Deck Wood Brightener to thoroughly mix. Dilute 1 part Wood Brightener to 4 parts water in a plastic container and mix well.

Apply: Thoroughly wet surface and ALL surrounding vegetation with water before application. Apply #1 Deck Wood Brightener solution to wet wood with sprayer, brush, or mop and scrub moderately with a stiff brush, working on small areas (20 - 30 sq. ft.) at a time. **Note:** Scrubbing is unnecessary if used after cleaning or stripping wood with #1 Deck Wood Cleaner or Stain Stripper. Let solution stand for 3 - 5 minutes, keeping wet with additional solution if necessary. On vertical surfaces begin applying solution at the bottom and work to the top. Application may be repeated if desired.

Rinse: Rinse wood and all surrounding vegetation thoroughly by flooding area with water from garden hose. Rinse vertical surfaces from bottom up to avoid streaking. Heavily weathered or soiled areas may need to be scrubbed with undiluted Wood Brightener and rinsed again.

Coverage: 500-1,000 sq. ft. per concentrated gallon depending on surface porosity & application method.

Cleanup: Clean tools and equipment immediately after each use with soap and water.

PRECAUTIONS

Keep out of reach of children. Do not take internally. Avoid contact with eyes and skin. Avoid breathing mist. Close container tightly after each use. Do not re-use containers. Store only in original container. The use of chemical splash goggles and rubber gloves is recommended when handling this product. Accumulation of product on ladders, scaffolding, decks, etc. may result in a slippery surface. Contains oxalic acid. Do not mix #1 Deck Wood Brightener with #1 Deck Wood Cleaner, chlorine bleach, or other chemicals.

FIRST AID

IF INHALED: Ensure fresh air breathing. Allow the victim to rest. In case of breathing difficulties, administer oxygen. Seek medical attention immediately. **IF SWALLOWED:** Rinse mouth with water (only if the person is conscious). Do NOT induce vomiting unless directed to do so by medical personnel. Immediately call a POISON CENTER or doctor/physician. Obtain emergency medical attention. **FOR SKIN CONTACT:** Rinse using water. Remove contaminated clothes. Wash skin thoroughly with mild soap and water. If skin irritation persists, seek medical attention. **FOR EYE CONTACT:** Immediately flush eyes thoroughly with water for at least 15 minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Seek medical attention immediately.

For additional information for this product, consult the Product Data Sheet or Safety Data Sheet available at www.1deck.com.

LIMITED WARRANTY

Our recommendations for use of this product are based upon tests believed to be reliable. Since field conditions vary widely, the user must determine the suitability of the product for the particular use and specific method(s) of application. Due to the fact that SaverSystems has no control over surface preparation and application methods, no guarantee as to results is offered, expressed or implied. SaverSystems warrants this product to be free from manufacturing defects.

SaverSystems' liability shall be limited in all events to supplying enough product to re-treat the specific areas to which defective product was applied. This warranty does not include the cost of labor application. SaverSystems shall not have any other liability including direct, incidental, or consequential damages. Some states do not allow the exclusion of incidental or consequential damages, so this limitation may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

Shelf Life: 36 months

PACKAGING

Available in one -gallon recyclable plastic containers.

TRANSPORT AND HANDLING

#1 Deck Wood Brightener is not considered hazardous under Department of Transportation regulations. Do not stack pallets. **Keep from freezing.**